

# AH-016 - Sphere



**Spare Part Number:** AH-016

**Net Weight:** 0.00kg

**Net Dimensions:** 0.00cm x 0.00cm x 0.00cm

## Description

### AH-016 Sphere $\varnothing 10$

The sphere is used to grant perfect positioning and alignment of the pin bar inside the pusher arm.

## Catalogues/Families

Suitable for the following equipment models:

CLASSIC 3 P	
CLASSIC 4 P	
EASY TO PLATE EVO 3 IPD	
EASY TO PLATE EVO 3 IPI	
EASY TO PLATE EVO 4 BPD	
EASY TO PLATE EVO 4 BPI	
EASY TO PLATE EVO 4 IPD	
EASY TO PLATE EVO 4 IPI	
EASY TO PLATE EVO 5	

BPD	
EASY TO PLATE EVO 5 BPI	
EASY TO PLATE EVO 5 IPD	
EASY TO PLATE EVO 5 IPI	
EVO 3 IP	
EVO 4 BP	
EVO 4 IP	
EVO 5 BP	
EVO 5 IP	
Spare Part Type	
Mechanical Component	
Spare Part Group	
Others	
Stock Type	
Standard Stock	