

---

# CP-260 - Servo Drive

**Spare Part Number:** CP-260

**Net Weight:** 0.00kg

**Net Dimensions:** 0.00cm x 0.00cm x 0.00cm

**Technical Datasheet:** [Protected Link](#)

## Description

### **CP-260 Servo Drive** (This component need to be programmed in the factory)

**Please note:** This part is not a direct replacement for CP-120.

Prior to ordering make sure you check what part is currently installed in your equipment.

Electronic device that translates low-energy command signals from a controller into high-energy voltage and current delivered to a servo motor. The command signal can represent the desired position, velocity or torque. The servo drive monitors feedback on the motor and automatically adjusts its output to correct for differences between the commanded value and actual.

NOTE: This component need to be programmed in the factory.

R88D-KT04H-ALT

400W

## Equipment reference

Equipment Model

Ref. 1

Ref. 2

Ref. 3

---

**EVO 2 A**

**EVO 3 A**

**EVO 3 IP**

**Servo Drive 1** for M2 -  
Washout Brushes (on the  
Left)

**Servo Drive 2** for M4 -  
Washout Brushes (on the  
Right)

**Servo Drive 3**  
Brush Oscillati  
Left)

**Easy to Plate EVO 3 IP I  
D**

**Easy to Plate EVO 3 IP I**

**EVO 4 IP**

**Servo Drive 1** for M2 -  
Washout Brushes (on the  
Left)

**Servo Drive 2** for M4 -  
Washout Brushes (on the  
Right)

**Servo Drive 3**  
Brush Oscillati  
Left)

**Easy to Plate EVO 4 IP  
D**

**Easy to Plate EVO 4 IP I**

**EVO 5 BP**

**Servo Drive 3**

**Servo Drive 4**

**Servo Drive 5**

**Easy to Plate EVO 5 BP  
D**

**Easy to Plate EVO 5 BP  
I**

**611 V3**

**M1**

**M2**

**M3**

### **Catalogues/Families**

Suitable for the following equipment models:

EASY TO PLATE EVO 4 IPD	
EASY TO PLATE EVO 4 IPI	
EASY TO PLATE EVO 5 BPD	
EASY TO PLATE EVO 5 BPI	
EASY TO PLATE EVO 5 IPD	
EASY TO PLATE EVO 5 IPI	
EVO 2 A	
EVO 3 A	
EVO 4 IP	

EVO 5 BP	
EVO 5 IP	
Spare Part Type	
Electrical Component	
Spare Part Group	
Others	
Stock Type	
Standard Stock	